





# Table of possible indications

| Event   | Tag (LED)  | Sound indication               | Notes   |
|---|--|--------------------------------|---|
| Warning of upcoming engine blocking               | —  | intermittent sound signals     | Take action to stop the car   |
| Discharged tag battery                            | image not found or type unknown<br>   | 3 sound signals                | Install new battery   |
| Normal security mode                              | image not found or type unknown<br>   | —                              | If the LED flashes once at button pressing, the tag is outside the coverage range. Security functions are disabled in the service mode. |
| Antihijack mode                                   | image not found or type unknown<br>  | —                              |   |
| Service mode                                      | image not found or type unknown<br> | —                              |   |
| Successful tag authorization                      | —  | 1 sound signal                 |   |
| Tag is absent. Prompt to enter the unlocking code | —  | long sound signal              | For immobilizers i95 ECO, i95.  |
| Normal mode. Tag is absent                        | —  | 1 sound signal every 2 minutes | If the tag was lost after motion start (in the normal security mode)  |
| Failure of the hood lock circuit                  | —  | 2 sound signals                | Fix hood lock circuit   |