

Recording and changing PIN-to-Drive code

Recording (changing) PIN-to-Drive code:

1. Disarm system if it is armed




2. Switch ignition Off
Off



3. Send SMS text command REG XXXX to enter Registration mode, where XXXX is emergency disarm code

4. Wait for the reply SMS: "Attention! Registration mode activated"

5. Switch ignition On
On



6. Enter new owner authorisation code by a sequence of vehicle's standard buttons pressing with no more than 3 sec push intervals

Press the standard car buttons



Every detected button push shall be followed by a single beep

7. In 3 sec after the full sequence finished system confirms code entry by 2 beeps

8. Enter the same buttons sequence once again

9. Correct button sequence repeated will be confirmed with 2 beeps

Invalid sequence entry will be followed by 4 beeps,
then retry code recording again from step 6

10. Switch ignition Off to exit Registration mode

Off

