

StarLine R6, R6 ECO

After firmware update, the security system settings remain the same.

For the security system update with "StarLine Master" app, use the Bluetooth indicator



module.

1. Connect the Bluetooth indicator module to the computer using a MicroUSB cable.
2. Open StarLine Master app.
3. Turn off ignition if it's on.
4. Press Valet (service) button of security system 6 times.
5. Turn on the ignition. Six light signals and six sound signals will follow.
6. Two short signals from the sound alarm will follow.
7. Make sure that the connected device and Bluetooth indicator module are detected. Select the device to be updated from the list.
8. Click "Update"
9. Chose Firmware version from Firmware library and press "Update".
10. Firmware download process will start on the device. After download is complete, a message confirming successful download will appear.

