



Light and sound indication

The security complex informs about its status by means of sound (horn) and light signals (turn signals):

-  — short signal;
-  — long signal.

Event	Light signals	Horn
Security activation		
Security activation with security zone breach		
Security activation with deactivation of «Hands free»		
Security activation with deactivation of «Hands free» mode with security zone breach		
Security deactivation		
Security deactivation (one of the zones was violated in the security cycle)		
Alarm	30 s	30 s
Warning level alarm		
Panic	10 s	10 s
Exit from service mode		